

MXZ™

***Pocket Saw
& Wrench***

PLEASE READ ALL INSTRUCTIONS PRIOR TO USE.

MXZ™

Pocket Saw

WITH Secure Blade 3-Position
Locking Mechanism

**SAWS THROUGH
ALMOST ANYTHING!**

**Metal-Steel / Iron / Aluminum
Masonry-Brick / Cinder Block
All Tiles-Wall / Floor / Ceramic
All Woods-Plywood / Flooring
Pipe-Iron / Copper / PVC
Glass-Rubber-Nails
Sheet Rock & More**

USAGE: (Refer to Illustrations below)

1. Slide the Lock Button down and hold.
2. Carefully pull out the blade. Once you reach the 2nd Locking Position, the Blade will lock in place.
3. To move the Blade to the 3rd Locking Position, slide the Lock Button down and hold. Move the blade away from the handle until it locks.
4. To bring the Blade to the 1st Locking Position (closed position), slide the Lock Button down and hold; slowly bring the blade towards the handle.

It's a great companion to the MXZ™ Wrench.



LOCK BUTTON



WORK SAFE AND SMART! PROTECT YOUR EYES,
Wear Safety Goggles/Protective Gear.



CAUTION: Make sure blade is in locked position
before cutting. Cut only those materials specified
for the blade.

FOR CUSTOMER SERVICE CALL: 1-800-423-4248

MXZ™


Pocket Wrench

USAGE:

Simply select the wrench size that you want to use and fold the set flat, forming a handle for easy use.

Use the **MXZ™ Pocket Wrench** anywhere you would use ordinary wrenches. Compact and durable, it's a great companion to MXZ™ Saw.

The sizes (from largest to smallest) are:
7/16, 3/8, 11/32, 5/16, 9/32, 1/4.



WRENCH SIZES:

7/16	5/16
3/8	9/32
11/32	1/4

FOR CUSTOMER SERVICE CALL: 1-800-423-4248

